



Sanctuary 2™ Energy Storage System (ESS)

12kW Hybrid Inverter / LFP 14.3kWh - 42.9kWh Battery



Installation Guide & Manual

Updated 8/15/25 (4)



READ THIS INSTALLATION GUIDE & MANUAL IN ITS ENTIRETY BEFORE OPERATING THE UNIT.

This unit provides safe, silent, and renewable electric power. It is very important to carefully read this Installation Guide before using the product. Keep this guide for future reference.

Carefully read and comply with all safety directives. Otherwise, personal bodily injury or death may result.

Symbols Used:



WARNING: Indicates a hazardous situation which, if not avoided, could result in injury or death.



CAUTION: Indicates a hazardous situation which, if not avoided, could result in minor injury or damage to the equipment.



NOTE: Indicates an important step or tip that leads to best results, but is not safety or damage related.

Follow these directives for safe use:



System Integrity: The inverter and all system components must not be disassembled or altered by unauthorized personnel. Unauthorized modifications can compromise system safety, void warranties, and result in serious injury or death.



Electrical Hazard: Always disconnect all power sources, including the AC and DC terminals, before performing any maintenance or cleaning. Use lockout/tagout procedures to ensure the system remains de-energized during maintenance.



Grounding Requirements: Proper grounding is essential for safe operation. Ensure that the system is connected to a permanent, grounded wiring system, and comply with all applicable grounding and bonding requirements.

SANCTUARY INSTALLATION GUIDE & MANUAL

-  **Load Calculations:** Ensure that all load connections are made following the installation guide's specifications for wire size, breaker sizing, and load balancing. Incorrect wiring or undersized breakers may lead to system failure and hazardous conditions.
-  **Heavy Equipment:** This system includes heavy equipment. Use lifting assistance during installation to prevent injury.
-  **Compliance with Regulations:** All installation and maintenance activities must comply with local, state, and national electrical codes and standards, including but not limited to UL 9540 and UL 1973. Adherence to these standards is mandatory to ensure safety and compliance.
-  **Final Continuity Check:** Do not power on the system until a final continuity check is performed to ensure all connections are secure and correctly installed.
-  **Battery Handling:** Strictly follow the manufacturer's instructions for handling and installation of batteries. Failure to do so may result in fire, explosion, or electric shock.
-  **Tool Usage:** Exercise caution when using metal tools around batteries and electrical components. Dropping tools can cause short circuits, leading to potential explosions or fires.
-  **Ventilation:** The installation location must provide adequate ventilation to prevent overheating of the system components. Ensure that the unit is installed in a well-ventilated area according to the manufacturer's recommendations.
-  **Qualified Personnel Only:** Installation, service, and maintenance of this Sanctuary system must be performed by qualified personnel/technicians. Only certified professionals with the appropriate training should install or service the unit, with or without a battery.
-  **Manual Reference:** Refer to the full installation and operation manual for detailed instructions and safety guidelines. Failure to follow these instructions can result in personal injury, property damage, or voiding of the warranty.

General Safety Guidelines

-  **Emergency Procedures:** In case of fire, evacuate the area and contact emergency services immediately. Do not attempt to extinguish battery fires with water. Use a Class D fire extinguisher suitable for lithium-ion batteries.
-  **Handling of Damaged Equipment:** If the unit or any of its components are damaged, do not operate the system. Contact a qualified technician, or ESS Support for inspection and repair.

SANCTUARY INSTALLATION GUIDE & MANUAL

Table of Contents

About the Sanctuary.....	6-8
• Sanctuary ESS Introduction.....	6
• Commonly Used Terms	7
• Sanctuary ESS Overview	8
• Inverter Overview	9-10
• Basic Wiring Diagram	11
• Parts and Components.....	12-14
Installation	15-19
• Installation Location.....	15
• Installation Precautions	17
• Mounting Brackets	18-19
Wiring the Sanctuary	20-40
• Battery Voltage Check.....	20
• Low Voltage DC Wiring	21-25
• BMS Communication Cable Wiring.....	23
• High Voltage DC Wiring	26-27
• Rapid Shutdown.....	28
• Remote Shutdown Switch.....	29
• AC Wiring.....	30-31
• Continuity Testing.....	32-34
• Generator Wiring	35-37
• AC Solar.....	38
• Parallel Inverter Connection.....	39
• Inverter Communication Wiring	40
• Inverter Wiring Diagram.....	41
• First-Time Power-Up	42
Technical Specifications	43
Warranty Program	44

Lion Sanctuary Introduction

Congratulations on your purchase of the Lion Energy Sanctuary ESS (Energy Storage System)! By investing in this innovative system, you've taken a proactive step to ensure uninterrupted power for your home. The Sanctuary is more than just a backup; it's your reliable partner during unexpected outages.

Here's what you can expect from your Sanctuary:

Peace of Mind

Rest assured knowing that with the Sanctuary installed, you're prepared for any power disruption. Whether it's a storm, maintenance, or grid failure, your home stays powered. Say goodbye to noisy generators and the hassle of refueling. The Sanctuary silently takes over, keeping your essential appliances running smoothly.

Advanced Technology at Your Fingertips

The Sanctuary incorporates cutting-edge lithium iron phosphate battery cells, ensuring reliable performance. Monitor your system's performance, charge status, and energy usage conveniently using the app on your smartphone or PC.

Customizable Backup Solution

Tailor your backup power to your specific needs. Whether it's essentials like lights and Wi-Fi, or your entire home, the Sanctuary adapts to your requirements. Our proprietary software optimizes energy usage, ensuring efficient operation and cost-effectiveness.

Tax Credits for Clean Energy

Take advantage of available tax credits for installing an energy storage system in your area, making clean energy more affordable and accessible.

Expandable Options

Consider expanding your Sanctuary system to cover longer outages if you're in a higher-risk area. It's an investment in your family's safety and comfort. Adding more inverters or batteries to your system allows for greater power usage and storage capacity.

For more details and support, please refer to our official page on the back of this manual. Thank you for choosing Lion Energy—we're committed to keeping your home powered!

Commonly Used Terms

AC-Coupled Solar: Previously considered cutting-edge, AC-coupled solar has evolved over the years. In an AC-coupled system, solar panels generate DC power, which is then converted into AC power by a separate solar inverter or micro inverters. This AC power can be used to power home appliances, stored in batteries, or sold to the grid. The Lion Energy Sanctuary System offers the advantage of energy storage, allowing you to utilize the power you produce.

Bypass: Bypass occurs when essential or backup loads are powered by the grid rather than the Sanctuary system. It serves as a temporary state during system maintenance, similar to taking a detour in a construction zone. A bypass switch allows homeowners or installers to temporarily bypass the Sanctuary system for servicing or troubleshooting while still maintaining power.

C (in relation to battery charge/discharge rate): The C rate for batteries is related to the Amp-hour capacity. For example, if a battery capacity is rated at 280Ah, then one C rate is 280 Amps, and 0.1C is 28A.

Consumption: Consumption refers to the power used by electrical loads or the entire home. CTs track consumption patterns, providing insights into energy usage.

CT (Current Transformer): CTs are devices used to measure the current flow in another circuit. In the Lion Energy System, external CTs are installed according to specific guidelines to accurately monitor current flow.

DC: DC refers to direct current, such as solar power and battery output.

Essential/Backup Loads: Essential or backup loads refer to the circuits and devices powered by the Lion Energy Sanctuary system. These loads are backed up by batteries, inverters, and solar power, ensuring uninterrupted power supply during outages. Excess solar power can offset the usage of non-essential loads, providing the benefits of self-consumption and energy savings.

Grid: The grid refers to the power supply from the utility company. Energy meters installed by utility companies measure the amount of power consumed by a home, typically billed monthly.

Integration with Existing Solar: The Lion Energy Sanctuary seamlessly integrates with almost any existing solar system on the market, ensuring compatibility and flexibility.

Load: A load refers to any active electrical circuit or device. Essential or backup loads are powered by the Sanctuary system.

MPPT: Maximum power point tracking. This is a type of power converter that is able to extract the maximum solar power available.

PV (Photovoltaic): PV refers to solar energy generation using photovoltaic cells. PV systems convert sunlight into electricity, contributing to sustainable power sources. The Sanctuary system works in conjunction with PV systems to store and distribute solar power efficiently.

Sanctuary ESS Overview

The Sanctuary is a multi-functional Energy Storage System (ESS) that incorporates the functions of an inverter, solar charger, battery charger, generator (not included), and lithium iron phosphate battery. The Sanctuary is commissioned and monitored through the Lion Energy App, available on smartphones and PCs.

The Sanctuary ESS can be considered your personal power plant. Whether you are covering essential loads or an entire home, correct sizing of the Sanctuary is key for the system to function properly. Before sizing, you must review the Sanctuary technical specifications on pages 40-41.

To size the system, consider the loads you want the Sanctuary to cover. Typical essential loads include refrigeration, furnace, lights, internet, and garage door.


Review your existing load center and identify the breaker size for each of the loads you want to cover. Note: any load larger than a 30-amp breaker will require multiple inverters. Using the code-compliant load calculation method for your jurisdiction, determine the number of continuous amps required to cover the desired loads. Each Sanctuary inverter can provide 33.3A AC off-grid (standalone). Any requirement above this will need additional Sanctuary inverters placed in parallel. Please contact Lion Energy for more details.

Note that the Sanctuary is only sold with both the inverter and battery as a system as both are required for full functionality of the unit. If paired with solar, the recommend minimum PV input is 3kW per battery of energy storage (14.3kWh each).


Basic System Architecture

This figure depicts the basic application of the Lion Sanctuary System. Power is fed into the system from the power grid, solar power array or generator to have a complete running system.


The Lion Sanctuary Energy Storage System can provide power for residences, including appliances, communication equipment, lights and other devices.




Inverter Overview



Inverter Side Controls



External Indicators (Lights) on System




- Green Light Solid:** System has no alarms
- Green Light Blinking:** Alarm state. An alarm can be as simple as the battery being lower than the target state of charge. An alarm means some inverter functions might not be available.
- Red Light:** Fault state. The inverter will shut down to protect itself if there is a fault detected. If a fault does not clear or comes back repeatedly, contact your installer.
- No Lights:** System is off.

Note: Alarms can be cleared automatically and may occur during times when the system is not yet fully commissioned. Some alarms or faults may need intervention such as a power-cycle to operate again. If a light is blinking, check the lion energy app to identify the alarm. If the alarm indicates a problem contact your installer for assistance.

Note: If the light does not come on and the button is pushed in, then contact your installer for assistance.

Basic Wiring Diagram



Professional wiring installation

All wiring must be performed by a professional electrician. Installation must be done by a Lion-Certified Installer.

Inverter Parts and Components



**Lion Hybrid Inverter
12kW**

1 Per Inverter



Antenna

1 Per Inverter



**Inverter Bracket
(#90000667)**

1 Per Inverter



**CT Pair 200 Amp 2/1
(#90000622)**

1 Per Inverter



**Mounting Spacer
(#90000668)**

2 Per Inverter



**Cat5 Cable (10')
(#90000136)**

1 Per Inverter



**AWG2 Black Eylet-Eyelet
Cable (24')
(#90000516)**

1 Per Inverter



**AWG2 Red Eylet-Eyelet
Cable (24')
(#90000517)**


1 Per Inverter



**Busbar Set
(#90000508)**

SANCTUARY INSTALLATION GUIDE & MANUAL

2 Per Inverter



Safety Clips
(#90000671)

1 Per Inverter



Inverter Wire Box
(#90000669)

1 Per Inverter



4mm Allen Drive
(#90000670)

1 Per Inverter



USB to RS485 Adapter
(#90000648)

1 Per Inverter



RJ45 Splitter (5-Port) 9"
(#90000666)

8 Per Inverter



**Hex Zinc Plated Lag
Screw 3/8" x 2"**
(#90000623)

Battery Parts and Components



Lion LFP Battery 14.3kWh

1 Per Battery



Battery Bracket
(#90000511)

1 Per Battery



Battery Wire Box
(#90000672)

8 Per Battery



Hex Zinc Plated Lag Screw 3/8" x 2"
(#90000623)

1 Per Battery



3' CAT5 (Ethernet) Cable
(#90000653)

1 Per Battery



AWG2 Battery Cable Red (55")
(#90000501)

1 Per Battery



AWG2 Battery Cable Black (55")
(#90000500)

1 Per Battery



RJ45 Splitter
(#90000647)

Installation Location


Before installing the Lion Sanctuary System (inverter/charger and battery), consider the following when choosing a location for installation:

- Install the Sanctuary System in a climate controlled location, regulated temperature between 32°F and 131°F. The Sanctuary ESS cannot be installed in a living space. In other words, the Sanctuary ESS needs to be installed in a garage or utility/storage room, not your family room.
- Be sure to keep other objects and surfaces away from the unit to permit adequate heat dissipation and provide space for wiring access. For proper air circulation, provide a clearance of at least 20 inches to the side and at least 12 inches above the inverter.
- To reduce installation costs, it is recommended to install the Sanctuary near existing electrical panels when possible.
- Note that the inverter, fans, and other internal components emit sound at 60dB (slightly louder than a standard computer fan).




Ignition Hazard

Do not install the system in an environment with flammable vapors, such as gasoline, as sparks from relays may ignite vapors



Sanctuary system dimensions without wire box

SANCTUARY INSTALLATION GUIDE & MANUAL



Sanctuary system dimensions with wire box

Installation Precautions


The Lion Sanctuary ESS battery is designed for wall mounting using a French Cleat system, while the inverter can be mounted either on top of the battery or directly to the wall. This system is suitable for both indoor and outdoor installations, provided appropriate measures are taken for each environment.

Ensure the installation adheres to the following guidelines:

General Conditions:

- Avoid direct sunlight.
- Do not install in areas where highly flammable materials are stored.
- Avoid potential explosive environments.
- Do not install directly in the path of cool air.
- Environmental Requirements:
 - Avoid environments with high precipitation or humidity exceeding 95%.
 - Ensure clearance for proper airflow.
 - Ambient temperature must remain between -4°F to 131°F
- Wall Installation Conditions:
 - Wall slope should not exceed $\pm 5^\circ$.
 - Use a solid mounting surface to mount inverter and battery mounting brackets. If mounting to brick or concrete, use proper fasteners following all local structural and building code.

Proper preparation and adherence to these guidelines will ensure a secure and effective installation for both indoor and outdoor environments. Once the wall or backing material is ready, proceed with installing the mounting brackets.




i Outdoor Installations

Indoor and outdoor installations are permitted for the Lion Energy system, provided appropriate measures are taken for each environment. For outdoor installations, ensure the system is protected against environmental factors such as **direct sunlight, rain, and extreme weather conditions**. For outdoor installations with high ambient temperatures, the system will automatically derate itself to protect the batteries and inverter from overheating. If derating is occurring, it is suggested to limit your energy consumption during these time periods, to allow the system to work at a lower power level and cool off.

Mounting Brackets

Step 1: Measure location of battery wall bracket

Step 2: Mount battery bracket



Step 3: Align the rectangular wall spacer with the battery bracket. This wall spacer is used to set the correct distance between the battery mounting bracket and the inverter mounting bracket.

Use the vertical orientation for including a wire box. If there will be no wire box between the inverter and the battery because of height constraints, use the horizontal orientation

Without wire box (rare): The rectangular spacer will be mounted horizontally. The holes in the spacer line up with the holes in the brackets. The rectangular spacer will be in front of the mounting brackets so that the mounting brackets are flush against the wall.

With wire box (common): The rectangular spacer will overlap the same amount in the vertical orientation as it does in the horizontal orientation, except there are no holes to line up.

Step 4: Align inverter with wall spacer.



Step 5: Mount inverter bracket to wall.

Step 6: Mount the battery by clipping it into the French cleat slot.

Step 7: Mount the inverter/wirebox combo by clipping it into the French cleat slot.

Step 8: Secure the wirebox to the battery using six M5 bolts.


Step 9: Secure Inverter to the wall using safety clips.



Multiple Inverter Setup

To provide proper airflow you must space the **inverters 20"** from each other.

SANCTUARY INSTALLATION GUIDE & MANUAL



Minimum battery spacing allowable is 4 inches as stated on UL Certificate.



Grounding Requirements

Risk of electric shock. When installing, the inverter must be grounded **first**. When dismantling, the grounding wire must be removed **last**.

Battery Voltage Check

Before connecting batteries in parallel, they should be within 0.5V of each other. If the batteries are not within 0.5V of each other, excessively high current may flow between batteries when they are connected in parallel.

If any battery is above 53.5V resting voltage at room temperature, it is probably above 98% charged. It can be quickly discharged down to 53.5V by running the inverter using battery power as its only power source.

If any battery is lower than 51.2V resting voltage at room temperature, it is probably lower than 7% charged. It should be charged up to within 0.5V of the other batteries before connecting them in parallel.

The following steps can be completed after commissioning the system.

Step 1. Before connecting the batteries, start with only the negative power cable connected to each battery, with the positive cable on each battery remaining unplugged. Note: This may trigger a battery disconnected alarm.

Step 2. Temporarily change these settings:

- For a single inverter system, set “inverter max charge current” to no more than 140A.
- For parallel inverter systems, set “system charge current” to no more than 140A.
- If there is not enough solar power available, set the inverters to battery priority mode so that the batteries will charge using grid power.


Step 3. Check the voltage on the inverter’s battery terminals. If it’s below 40V, use the battery awaken function in the web app. After a minute, the voltage should rise above 50V. Then plug in the positive battery cable for the lowest voltage battery.

Step 4. After the lowest battery is charged up to within 0.5V of the next lowest battery, plug in the positive cable of the next lowest battery.

Step 5. Continue charging and repeat step 4 until all batteries are plugged in.

Step 6. Change the “system charge current” back to the original setting. Emergency mode can be turned off.

Low Voltage DC Wiring: 1 Inverter



When wiring 1 inverter to 1 battery,

first check the voltage of the Battery. It should be between 45-55.6VDC. If it is not, contact LionESS support at (435) 244-3352.

Connect the battery cables to the inverter **first**. Now connect the cables to the battery receptacles last.

Next, connect the BMS communication cable to the RJ45 port labeled BMS on the inverter and connect the 4-pin aviation style connector to the battery.

When wiring 1 inverter to multiple batteries,





Step 1. Connect the provided eyelet to eyelet battery cables to the inverter first, then to the provided busbars.

Step 2. Using the provided battery cables, connect all negative cables from the negative busbar to the negative battery receptacles,

Step 3. Now connect the positive cables from the positive busbar to the positive battery receptacles.

Step 4. Use a standard Ethernet cable (T568A or T568B wiring) to connect the parent inverter to the first battery. Use a standard Ethernet cable to connect from one battery to the next until all batteries are daisy-chained together. See step 4 in the figure below.


SANCTUARY INSTALLATION GUIDE & MANUAL



Battery Voltage

When connecting multiple batteries, check voltage on each battery first. Batteries must be within 0.5V in order to connect in parallel.

BMS Communication Cable Wiring



Low Voltage DC Wiring: Multiple Inverter


(3 Inverters, 6 Batteries)

- Step 1.** Mount busbars directly below each inverter. Connect busbars to each other.
- Step 2.** Using the provided eyelet to eyelet cables connect each inverter to their corresponding busbar.
- Step 3.** Connect the negative (-) battery cables to the battery receptacles.
- Step 4.** Connect the positive (+) battery cables to the battery receptacles last.
- Step 5.** Use a standard Ethernet cable (T568A or T568B wiring) to connect the parent inverter to the first battery. Use a standard Ethernet cable to connect from one battery to the next until all batteries are daisy-chained together. See step 5 in the figure below.

Battery Voltage

When connecting multiple batteries, check voltage on each battery first. Batteries must be within 0.5V in order to connect in parallel. See instructions on page 18.


When connecting busbars battery cables must be the same length throughout the entire system and have a correct degree and voltage rating.




For more detailed instructions on connecting the communication cables between batteries see page 30-31

SANCTUARY INSTALLATION GUIDE & MANUAL


Step 3



Step 4



Step 5



High Voltage DC Wiring

The Sanctuary inverter has 4 MPPTs that are capable of 3 kW of solar each, for a total of 12 kW.


Usable voltage range: 120V to 500V

Maximum PV ISC rating: 22A

When configuring your PV strings, you must also account for the increase in panel voltage at low temperatures so that the 500V maximum open circuit voltage is not exceeded. Refer to the Sanctuary technical specifications for further detail.

For higher wattage strings, MPPT 1&2 and 3&4 can be set in parallel. This allows up to a 6 kW PV string to be connected to both MPPT 1&2 at the same time. MPPT 3&4 are also put in parallel. In this mode, it effectively changes the four 3 kW MPPTs into two 6 kW MPPTs. The parallel connection is made manually, external to the inverter. Change the setting Solar Input Type from “Independent” to “Dual MPPT”.

If the panels use optimizers such as Tigo TS4-A-O, remember to enable the setting “PV Optimizer” after commissioning. It is no problem to enable that setting even if there are no optimizers present.



Correctly connect positive and negative

Before making the final DC connection or turning on the high-voltage DC switch / disconnect, be sure the positive (+) connects to positive (+) and negative (-) connects to negative (-).



Professional wiring installation

All wiring must be performed by a licensed electrician.



High voltage

Make connections while the unit is powered off. The PV(-) terminals are typically at -240V DC while the unit is in operation.

PV Connection

It is important for system safety and efficient operation to use the appropriate cables for the PV module connections. To reduce risk of injury, use the recommended cable size given in the table below. The Sanctuary system accepts up to 10 AWG wire for PV connection.

PV Module Wire Connection

Verify correct polarity of all wire connections for the PV modules and PV input connectors. Insert the wires and connect the positive pole (+) of the connection wire to the positive pole (+) of the PV input connector. Connect the negative pole (-) of the connection wire to the negative pole (-) of the PV input connector.



Use surge protection

It is recommended to use a surge protection device for your PV line(s). Otherwise, damage from lightning strike to a PV module may result in damage to the system.



Ungrounded PV - DO NOT ground PV Lines

If the grid is turned on when PV(-) is connected to ground, catastrophic failure will occur. See first-time power-up sequence on page 41.



Avoid PV modules with current leakage

To avoid any malfunction, do not connect any PV modules with possible ground leakage to the inverter. When using PV modules, be sure there is no continuity between PV(-) and ground.



Diagnose PV to GND Leakage

Even though there can be voltage between PV(+) and PV(-), there shouldn't be any voltage between PV(+) and GND or PV(-) and GND. If there is, it indicates a current path. During on-grid operation, the PV(-) terminals are usually around -240V DC with respect to GND.

1. Rotate the PV Disconnect switch to the off position.
2. Measure voltage between PV(-) and GND. You should get about 0V. If it's approximately 0V, measure continuity between PV(-) and GND. It should read open circuit.
3. Measure voltage between PV(+) and GND. You should get about 0V. If it's approximately 0V, measure continuity between PV(+) and GND. It should read open circuit.
4. If Module Level Power Electronics (MLPE) are used, this test may not detect PV to ground leakage paths if the Rapid Solar Shutdown (RSS) system is not turning the PV panels on.


Rapid Shutdown

The national electric code (NEC) requires the use of a rapid shutdown system for PV systems on buildings. This is for first responder safety during rooftop ventilation or rescue operations. See NEC, section 690.12 for more information.

The Sanctuary inverter has a built in 12 Volt DC, 1A power supply for a rapid shutdown (RS) transmitter. The RS transmitter is polarity sensitive.


The 12 Volt supply is located as highlighted below on the pins labeled +12V_COM and GND_COM.

When either the remote shutdown switch is pressed (open circuit), or the power button is turned off, the inverters will turn off, including this 12V power source.



Remote Shutdown Switch

If you are installing a remote shutdown switch, unplug the connector with the black wire loop (indicated by the yellow highlight in this picture). Remove the wire loop and connect your remote shutdown switch in its place. The remote shutdown switch should use the normally closed position for the inverters to be turned on. When you shut off the system with the remote shutdown switch, it should open this circuit.



AC Wiring: 1 Inverter


For grid-tied installation, the Sanctuary is capable of up to 100 Amp grid-supplied pass-through. The grid input power must come from an appropriately sized circuit breaker, up to 100A. The maximum wire size the inverter terminals can accept is 2 AWG copper.

Inverter to cover Essential Loads

Install two breakers into the Main Panel.

One breaker will be the grid input for the Sanctuary Inverter. The load output of the Sanctuary Inverter will go to a 3-position manual transfer switch. The next breaker will go from the Main Panel directly to the 3-position manual transfer switch. From the manual transfer switch, lines will go directly into the Essential Loads Panel.

** Take note: A 3-position manual transfer switch is recommended but not required **



AC Wiring: Multiple Inverter


For grid-tied installation, the Sanctuary is capable of up to 100 Amp grid-supplied pass-through per inverter. The grid input power must come from an appropriately sized circuit breaker, up to 100A. The maximum wire size the inverter terminals can accept is 2 AWG copper.

3 Inverters to cover whole home backup

For the inverters' load outputs, install a combiner panel with three breakers, one for each inverter. These breakers will connect to the load outputs of each of the Sanctuary inverters. The combiner panel can connect to one input of a manual transfer switch. The other input of the manual transfer switch can connect to a grid breaker. The output of the manual transfer switch will connect to the essential loads panel.

** Take note: A 3-position manual transfer switch is recommended but not required **

** Anytime multiple inverters are installed, a continuity test must be performed to ensure all phases match before powering up **



L1 L2 PHASING

It is of vital importance that the grid input and load output phases on multiple breakers match. If a phase is crossed, that will result in a short circuit from line1 to line2. Crossing phases WILL cause a catastrophic failure on the equipment **See continuity testing on page 32**



Breaker Sizing

The three breakers feeding the sanctuary system from the main panel need to be the same amp rating with a maximum of 100A each. The fourth breaker that directly feeds the manual bypass should be roughly equal to the total of the other three breakers. For (example 3 breakers @ 70A ea to feed the sanctuary units and a 200A breaker to go to the manual transfer panel.)

Continuity Testing: Multiple Inverters


When installing a multiple inverter Sanctuary, it is essential to not cross phases. This means, Line 1 needs to remain Line 1 on Grid Input and Load Output for all Inverters. Line 2 needs to remain Line 2 on Grid Input and Load Output for all Inverters. Neutral needs to remain the same as well. There are three ways phases can be crossed. Physical wiring, the physical bussing of the service panel, and the breaker itself. A simple way to ensure phases have not been crossed is to conduct a continuity test.

When installing multiple inverters, it is **REQUIRED** that you individually test the phasing on the grid input, generator input, and load output terminals of each inverter.


Grid Input Continuity Testing

If there is no user-accessible AC disconnect above the inverter grid breakers, use caution when making measurements on live circuits.

- Step 1.** Make sure the AC power button on each inverter is turned off.
- Step 2.** Turn off the load breakers in the load combiner panel so that the load port on each of the inverters is disconnected from the other inverters.
- Step 3.** Turn off the power feeding the grid breakers for the Sanctuary inverters, but leave the inverter grid breakers in the on position. If there is no disconnect above the inverters' grid breakers, measurements will be done on live wires.
- Step 4.** Measure voltage between grid L1 on the first inverter and grid L1 on the next inverter. It should read zero volts. Check continuity between grid L1 on the first inverter and grid L1 on the second inverter. These should be close to zero ohms. Measure voltage between grid L1 on the second inverter to grid L1 on the third inverter. It should read zero volts. Grid L1 on the second inverter to grid L1 on the third inverter should also be close to zero ohms.
- Step 5.** Measure voltage between L2 on the first inverter and L2 on the next inverter. It should read zero volts. Check continuity between L2 on the first inverter and L2 on the second inverter. These should be close to zero ohms. Measure voltage on L2 from the second inverter to L2 on the third inverter. It should read zero volts. L2 on the second to L2 on the third inverter should also be close to zero ohms.
- Step 6.** Measure voltage between L1 and L2 on each inverter. If grid power is present, it should read 240V on each inverter. If grid power is not present and no voltage is detected, there should be no continuity between L1 and L2. Do not measure continuity across 240V.
- Step 7.** On each inverter, measure voltage between grid neutral and ground. It should read zero volts. Measure continuity between grid neutral and ground. It should be close to zero ohms due to the neutral to ground bonding in the first panel after the utility meter.



Load Output Continuity Testing



Load Output Continuity Testing

After confirming that the inverters have all power sources turned off, there should be no voltage present at the grid input, generator input, or load output terminals. Start by checking the panel to ensure there is no voltage present on the panel. (Note: If voltage is present and the inverters are turned off, there may be another power source feeding the panel.) After confirming the panel is not live, you can now turn on the load output breakers from each inverter. This allows the circuit between the inverters to be closed so you will be able to check continuity of phases between each inverter.

If you installed a manual bypass switch, switch the essential loads panel to the grid power position. This will disconnect the loads from the inverter load breakers. If there is not a manual bypass switch, turn off all the breakers in the essential loads panel for this test. Leave the inverters' load output breakers on so that each inverter's load port is connected to the other inverters' load ports.

With the inverters off, there should be no voltage present on the load terminals of any inverter. Measure continuity between load L1 and load L2 on each inverter. Each should be open circuit. If any of these tests do not pass, it could be a crossed phase or incorrect test setup (such as load breakers not on, or loads connected to the inverter output).

Load Output Continuity Testing: L1

Measure continuity between load L1 of the parent and load L1 of the child inverter. It should be close to zero ohms. Measure continuity between load L1 of the child inverter and load L1 of the next child inverter. It should also be close to zero ohms.

Load Output Continuity Testing: L2

Measure continuity between load L2 of the parent and load L2 of the child inverter. It should be close to zero ohms. Measure continuity between load L2 of the child inverter and load L2 of the next child inverter. It should also be close to zero ohms.

Load Output Short Circuit Check


With power still off, measure continuity between load L1 and load L2 of each inverter. It should be open circuit on each inverter.

If any of these tests don't pass, the wiring needs to be corrected before proceeding.

Turn off the AC output breakers. In commission, you will be prompted to reconnect and check.

CT Installation

Using the provided CTs, clamp the CT labeled line1 around line1 feeding the main panel. Clamp the other CT labeled line2 around line2 feeding the main panel. The arrows need to point towards the grid so that the correct current direction is read.




In a multiple inverter system only the parent inverter has CTs connected as shown above.

Generator Wiring : 1 Inverter

The Sanctuary ESS is compatible with 240V split phase home backup generators. The Sanctuary can function with both a manual or an auto start feature. It can accept up to 8kW of input power through the Gen input to cover loads and to charge batteries. The generator functions are only available when the grid is not present.

To wire a generator to the Sanctuary ESS, the generator AC output will go directly into the Gen input of the Sanctuary inverter. If the generator has a remote two wire auto start feature, these lines must be wired into the DRYO_1B and DRYO_1A ports on the inverter circuit board.



Generator Wiring: Multiple Inverter




L1 L2 PHASING

It is of vital importance that the generator input phases on multiple breakers match. Crossing phases will short-circuit the generator and may damage equipment. **Follow the procedure for generator input continuity testing on page 36.**

The Sanctuary ESS is compatible with 240V Split Phase home backup Generators. The Sanctuary can function with both a manual or an auto start feature. It can accept up to 8kW of input power through the Gen Input to cover loads and to charge batteries. The Generator function is only available when the grid is not present.

When the install consists of multiple inverters, the generator AC output needs to be wired to a combiner panel. From the combiner panel, lines will go to each Sanctuary Inverter's Gen Inputs. If the generator has a remote two wire auto start feature, these lines must be wired into the parent inverter's DRY0_1B and DRY0_1A inputs.


***** Any time multiple inverters are installed, a continuity test must be performed to ensure all phases match before powering up.**



Breaker Sizing

The three breakers feeding the sanctuary system from the generator combiner panel need to be the same amp rating with a maximum of 40A each.

Generator Input Continuity Testing



- Step 1.** Make sure the generator is off. If using AC solar, Make sure the AC power button on each inverter is turned off. If the inverter is turned on with AC solar enabled, the generator port will be connected to grid power through internal relays.
- Step 2.** Leave the generator (or AC solar) combiner breakers in the on position.
- Step 3.** Make sure the power is off by measuring voltage between L1 and L2 on each inverter's generator port.
- Step 4.** Check continuity between generator L1 on the first inverter and generator L1 on the second inverter. These should be close to zero ohms. Generator L1 on the second inverter to generator L1 on the third inverter should also be close to zero ohms.
- Step 5.** Check continuity between generator L2 on the first inverter and generator L2 on the second inverter. These should be close to zero ohms. Generator L2 on the second inverter to generator L2 on the third inverter should also be close to zero ohms.
- Step 6.** Turn off the breaker on the generator. Measure continuity between the generator L1 and generator L2 ports on the inverter. It should be open circuit.

AC Solar


The Sanctuary ESS supports AC-coupled solar and provides battery backup for existing grid-tied PV systems. Excess solar power is routed to charge the battery. The generator port on each inverter may be wired either to AC-coupled PV or to a generator, but never both at the same time.

System Capability

- Supports up to 8 kW of AC-coupled PV or generator power per system, regardless of inverter model.
- Single-inverter setup: land up to 8 kW of AC-coupled PV or a generator on that inverter's generator port.
- Multi-inverter setup: use a combiner panel to distribute the chosen source (AC PV / generator) to every inverter's generator port. All inverters must receive the same source type.

Installation Guidelines

- Phase integrity: do not cross L1 / L2 in PV or generator wiring. Crossing phases will short L1 to L2 and may damage equipment.
- For sites that require both AC-coupled PV and a generator, land the AC-coupled PV on the main service panel (outside the Sanctuary system) and wire the generator to each inverter's generator port. In this configuration, AC PV is not monitored by the Sanctuary system and cannot be used during a grid-down event.





i AC Solar Considerations

- The diagram provided is for illustrative purposes only. Actual system configuration may vary based on installation requirements.
- In a multiple inverter setup, only one input type—either generator or AC solar—may be used across all inverters; mixing the two is not supported.
- Auto-start is disabled whenever AC-coupled PV is connected to the generator port.

Parallel Inverter Connection



When wiring 2 inverters in parallel, using the provided cat5 cable:

Connect cat5 cable on Parallel B located on the Parent Inverter to Parallel A on the child Inverter as shown.



When wiring 3 inverters in parallel, using the provided cat5 cables:

Connect the first cat5 cable on Parallel B located on the Parent Inverter to Parallel A on the Child 1 Inverter as shown.



Next, connect a second Cat5 cable from Parallel B on Child 1 to Parallel A on Child 2.


SANCTUARY INSTALLATION GUIDE

You're now ready to begin the commissioning process.

Please make sure you have completed the training and have received a login to the Lion Energy App.
Please visit smart.lionenergy.com


Inverter Communication (Comm) Wiring

Using cat5 patch cables, connect the Wifi ports to a splitter that connects to the WCM.



Inverter Wiring Diagram

- Parallel Communication Wiring
- Communication Wiring
- BMS Communication Cable Wiring



First-Time Power-Up

Before turning on the grid breakers to any inverters, it is critical to go through the first-time power-up sequence. This checks the PV wiring for ground leakage. There can be no continuity between PV(-) and ground or PV(+) and ground. Otherwise, catastrophic damage can occur.

- Step 1.** Make sure grid breakers are turned off to all inverters. Make sure the load combiner breakers are turned off for all inverters (applies to parallel systems only).
- Step 2.** Make sure batteries are connected to the inverters.
- Step 3.** Turn on the bottom power switch labeled “Complete System Shutdown” on all inverters so that the control board has power. Leave the middle button (AC/DC) off.
- Step 4.** Commission the System.
- Step 5.** After commissioning the system, turn on the load combiner breakers.
- Step 6.** On all inverters, turn the PV DISCONNECT switch on. You should be getting voltage from the PV panels to the inverters now.
- Step 7.** Wait at least two minutes. After a minute, the inverter should start the PV insulation check test. You might be able to hear the relay clicking. If the front panel LED turns on orange or red, it failed the test. Do not proceed powering up until the PV wiring has been corrected so that there is no path from PV(+) to GND or PV(-) to GND. If the test failed, the inverter must be completely powered down.
- Step 8.** On all inverters, turn the AC/DC switches on and wait two minutes. The load will power on within about 30 seconds. If the red light comes on, power off all the inverters (turn off all three buttons) and fix the PV wiring. Do NOT turn on any grid breakers until the PV wiring is fixed. Otherwise, catastrophic equipment failure may occur.
- Step 9.** Turn on on the grid breakers to all inverters.

Lion Sanctuary 2™ Technical Specifications

Lion Sanctuary 2™ Energy Storage System (ESS)

Sanctuary ESS 12-14.3

Sanctuary ESS 12-28.6

Sanctuary ESS 12-42.9

Major System Components

Lion LFP Battery 14.3kWh

Lion Hybrid Inverter 12kW - Grid Support

Interactive Inverter

System Configurations



Sanctuary ESS 12-14.3



Sanctuary ESS 12-28.6



Sanctuary ESS 12-42.9

System Details

Full System Weight: 12-14.3 400lbs.
12-28.6 690lbs.
12-42.9 980lbs.

Single Cycle Round Trip Efficiency (SCRTE): 89%



Install in shaded locations.
Do NOT install in direct sunlight.

SANCTUARY INSTALLATION GUIDE & MANUAL

Lion Hybrid Inverter (12kW) - Grid Support Interactive Inverter

PV Input

Max PV Input Power	12kW
MPPT Input Voltage Range	120-500V
Max Input Current per MPPT	14A*4
Max Short Circuit Current per MPPT	22A
AC Solar Max	8kW

AC Output (On Grid)

Nominal Output Power	8kW
Max Apparent Power Output	8.8kW
Nominal AC Output Current	33.3A
Max. AC Power Output	36.7A
Output Voltage Range	120V/240V Split phase
Grid Frequency (Optional)	60Hz
Max Grid Passthrough	100A
Output THDI	< 3%
Maximum Output Fault Current (AC) and Duration	71.5A (1 Cycle)/ 72.0A (3 Cycles) / 72.4 (5 Cycles)

AC Output (EPS)

Nominal Output Power	8kW
Power Factor Range	-0.8~+0.8
EPS Voltage Range	110-120/220-240V Split-Phase
EPS Frequency (Optional)	60Hz
Output THDU	< 2%

Battery

Battery Voltage Range	40V~60V
Max Charging Current	190A
Max Discharging Current	190A

General Data

Humidity	0-95%
Ingress Protection	Type 3R, IP65
Max Efficiency	97.8%
PV DC AFCI	Type 1
PVRSS	Tigo RSS Transmitters (RS2)
Weight	110lbs
Dimensions (HxWxD)	33.6" x 18.50" x 10.08"
Compliance	UL9540, UL1741:2021, UL1741 SB:2021, UL1741 SA:2018, UL1699B:2018, IEEE Std 1547:2018, IEEE Std 1547a:2020, IEEE Std 1547.1:2020, CPUC Rule21:2017, FCC 15 class-B

GEN / AC-Coupled PV Connection

Terminals	L1, L2, N, PE (split-phase 120/240V)
Source	Single source only—generator or AC-coupled solar
Max Apparent Power	8kW per inverter
Auto-Start	Supported

Lion LFP Battery 14.3kWh

Battery Type	Lithium Iron Phosphate
Voltage Range	40 - 58.4VDC
Rated Voltage	51.2VDC
Capacity	14.3kWh
Usable Capacity	90%
Isc rating (SCCR)	2040A/7ms
Parallelable Capacity	43kWh Max
Max Parallelable Overcurrent Protective Device	240A
Quantity	3 Max
Charging Temperature Range / Current	32° to 131° F / 150A
Discharging Temperature Range / Current	-4° to 131° F / 160A
Derate Range	Below 50°F, Above 104°F
Weight	290lbs
Dimensions (HxWxD)	44.4" x 18.50" x 9.75"
Compliance	UL1973, UL9540, UL9540A

SANCTUARY INSTALLATION GUIDE & MANUAL

Notes:

[illegible]



LIONENERGY™



385.375.8191
Monday - Friday
9:00 AM - 5:00 PM MST



735 S. Auto Mall Drive Suite 200
American Fork, Utah
84003



info@lionenergy.com
www.lionenergy.com
@lionenergy