



LIONENERGY™

USING THE LION PROWLER

- To check the Prowler's charge, press and hold the power button for 1 second. Indicator lights (left of the button) will show charge level—4 lights means full.
- To charge the Prowler, plug the USB-A end of the included cable into a power source, and the USB-C end into the Prowler (under the rubber flap near the power button).

USB CHARGING

- To charge a device, use the included cable (or your own) to connect your device (phone, tablet, etc.) to an output port on the end of the Prowler near the power button (under the rubber flap).
- Press and hold the power button for 1 second to begin charging.
- When done, press and hold the power button for about 3 seconds—until all lights turn off—to power down the Prowler.

WIRELESS PHONE CHARGING

- Press the power button twice to activate wireless charging. A red indicator light (far left of the power button) will turn on.
- Place your smartphone directly on top of the Prowler. A green light will appear, and charging will begin. *Note: Some phone cases may block wireless charging.*
- To turn off wireless charging, press the power button twice again.

USING THE FLASHLIGHT/LAMP

- **Flashlight:** Press and hold the flashlight button (next to the power button) for 1 second to turn on/off.
- **SOS Mode:** Press and hold the flashlight button for 3 seconds to turn on. Press and hold again for 1 second to turn off.
- **Lamp:** Double-press the flashlight button to toggle the Lamp on/off.

Get more information at www.lionenergy.com

